

ArcOne® is a Division of A.C.E. International Company
85 Independence Drive, Taunton, MA 02780, USA
TEL: 1+(508) 884-9600 • TOLL FREE: +1 800) 223-4685 • FAX: (508) 884-9666
PLEASE VISIT OUR WEBSITE: www.arc1weldsafe.com

M-EUROALTADF-2003 REV K

Table of Contents	Page
Preparations for Use	1
Technical Information / Use	
Limitations of Use	3
Care and Maintenance	4
Spatter Protection	4
Parts Selection Guide	4
Filter Specifications	8
Significance of Markings:	10
Shade Selection Guide	11
Filter Removal Diagram	11

Preparations for Use

WARNING, materials which may come in contact with the wearer's skin may cause an allergic reaction to susceptible individuals.

Filters:

Before you begin welding always inspect your filter to ensure it is not damaged. Check to see if the filter protection plates (cover plates) are clean, clear, undamaged, and securely attached to the helmet and covering the auto-darkening filter both front and rear. Make sure the filter will turn dark before using. Direct toward a bright light source or use a torch striker. Direct sunlight may not darken the filter.

WARNING, never begin welding without first checking to see if the correct front and rear protection plates are in place (See Part Selection Guide section for part numbers). Failure to protect the welding filter may cause damage and become a safety hazard should the UV/IR protection be compromised from spatter or cracks from impact. DAMAGE CAUSED BY ABUSE SUCH AS EXCESSIVE TEMPERATURES, CRACKS FROM IMPACT, AND PITTING FROM SPATTER CAUSED BY POOR MAINTENANCE WILL VOID WARRANTY.

Not for use in overhead welding.

WARNING, toughened mineral filter oculars shall only be used in conjunction with a suitable backing ocular.

Welding Helmets:

Before you begin welding make sure there is no damage to the helmet shell including, but not limited to, cracks, holes, and melting. Ensure that the springs holding the filter are not broken or corroded. Do not use the helmet if any of these conditions exist and contact your distributor for replacement parts. Use only replacement components as specified for each welding helmet in accordance with this user manual.

Adjust headgear for comfort and proper sight-line through the filter (see Parts Selection Guide).

WARNING, other safety precautions such as protective clothing, adequate ventilation, breathing protection (e.g. powered air purifying respirator), fire extinguisher, and protection for co-workers, should also be considered. Consult an Industrial Hygenist to ensure adequate protection is being provided.

Technical Information / Use

Filters:

ArcOne® auto-darkening filters protect the user against harmful ultra-violet and infrared UV/IR rays, both in the dark and light state. No matter what shade the filter is set to the UV/IR protection is provided. When used properly, the filter will prevent your eyes from being burned by optical radiation.

WARNING, severe burns are possible with a damaged lens (cracks, pits, holes, etc.). Do not use damaged lens. Optical radiation can possibly enter in from behind the helmet from other welders welding in the immediate area.

Shade Adjustment (refer to Fig. 1 through 4):

See Filter Specifications (Table 1) for filter specifications.

See CE Shade Selection Guide (Table 2) for recommended shades for arc welding applications.

Digital LCD Controlled Variable Filters (Fig. 1): Briefly press the Mode button (Fig. 1), the LCD mode will flash to indicate the current setting. Press and hold the + or - button to change the setting. The number will change on LCD.

Analog Controlled Variable Filters (Fig. 2):

External Control: Set filter to desired dark shade with the shade knob located on the outside of the helmet. The Shade Number will change on the LCD (Fig. 3 & 4) as the user turns the knob up or down. **NOTE:** The 5130V has a switch on the control case to switch the shade range from 5-9 to 9-13.

Internal Control: Set filter to desired dark shade with the shade knob located on the filter.

The configuration of internal controls vary; however, each knob is labled according to function, also, buttons are labeled or marked according to function.



Figure 1: Digital Controls




Figure 2: Analog Controls

Sensitivity Adjustment

Digitally Controlled Filters: Briefly press the Mode button (Fig. 1), the LCD mode will flash to indicate the current setting (Fig. 3). Press and hold the + or - button to change the setting.

Analog Controlled Filters: Models with external or internal control turn the knob to change the sensitivity (Fig. 2), increasing or decreasing it. Some Digital LCD models will display the level of sensitivity (Fig. 1), where more bars equals increased sensitivity.

X-Mode:

Filters 5000VX, 5130VX, 5500VX, 7000VX, 7500VX, and the iDF48 have an X-TIG mode for ideal for TIG welding applications. When set to X-TIG, the digital display will show "X-TIG" in the sensitivity column (Fig. 3b).

5000VX and **7000VX**: X-TIG is accessed via an external switch on the outside control. Turn until the control knob clicks into place and the LCD displays "X-TIG."

5130VX, 5500VX, and 7500VX: Use the + button to set the sensitivity to the highest setting.

iDF48: Press the Mode button for three (3) seconds until the X-TIG icon appears (Fig. 4).



Figure 3a: LCD Readout (4000V, 4500V, 5000V, 5500V, 5130V, 7000V, and 7500V)



Figure 3b: LCD Readout (5000VX, 5500VX, 5130VX, 7000VX, and 7500VX)



Figure 4: LCD Readout (iDF48)

Delay Adjustment and Grind Mode (not on all models)

Digital Controlled Filters: Briefly press the Mode button (Fig. 1), the LCD mode will flash to indicate the current setting (Fig. 3 or 4). Press and hold the + or - button to change the setting. **NOTE:** Some models have a dedicated Delay button with the + or - to change the setting.

6000VI4: Press the Delay button on the back of the control center to turn delay on or off.

Intelligent Darkening Filter (IDF) Modes

To switch from one mode to another Press AND Hold down the Mode button for two seconds. To cycle through modes continue depressing the Mode button. (***NOTE: Modes will not switch when in Grind Mode.)

Low Shade Mode: Dark Shades 5-8 available in this mode. Arc detection to 10 Amps.

Auto-Variable Mode: LCD displays "AUTO" (Fig. 4). Filter automatically responds to the intensity of the welding arc and sets the filter to the appropriate dark shade. The Auto-Variable mode is dependent upon light intensity of the arc and distance from the filter to the arc. The user can further adjust the dark shade up or down one shade number for comfort while the "(•)" icon is flashing. This mode has one memory position for each shade in the dark state; i.e. 9, 10, 11, 12, and 13. (**NOTE**: Shade 13 cannot be set higher than 13. This mode only works on split range; i.e. 5-9/9-13 filters in the higher shade range.) To reset all memory slots press and hold both mode and delay buttons for two (2) seconds.

iTIG Mode: Upon entering iTIG mode, where LCD displays "TIG" icon and flashing "(*)" (Fig. 4) user first sets lower desired shade while the "(*)" flashes. After approximately five (5) seconds of not turning the shade knob the flashing stops and the user can then set the desired upper shade. The lowest possible shade is fixed according to the standard to which the filter has been tested (example: iDF48, iTIG in 9-13 range shade 9 lowest and shade 13 highest, in 5-9 range shade 7 lowest and shade 9 highest.)

Welding Helmets:

Welding helmets are designed to provide protection against UV/IR radiation around the user's face. ArcOne® welding helmets meet/exceed face coverage defined by CE standards. ArcOne® welding helmets are suitable for arc welding. Refer to any or all of the following standards for more specifications: ANSI Z87, CAN/CSA Z94.3, and CE EN 166 & 175.

Limitations of Use

Filters:

ArcOne® welding filters are not designed for oxy-acetylene, laser, or very low amperage welding applications. Arc detection may be impaired due to amperage, distance from the arc, welding current frequency, electrode type, shielding gasses, and lighting conditions.

DO NOT weld with filter in the light state. If the filter fails to turn dark immediately stop use and contact a service provider for help.

Welding Helmets:

CAUTION, not meant to protect against Severe Impact, explosives, fragments from grinding wheels, abrasive discs, and hazardous fluids. Use secondary impact protection, such as safety glasses.

DO NOT use this helmet without proper training from a certified welder or welding instructor. **DO NOT** use this helmet in an excessive heat environment where the operation of the filter becomes non-functional due to exceeding the temperature ratings of the electronic components.

Care and Maintenance

NOTE: Replacement components must be used in accordance with these instructions. Failure to use ArcOne® replacement components in accordance with these instructions voids certification of this product.

Filters:

Filters require virtually no maintenance other than periodic cleaning when the lens, solar panel, and/or sensor(s) become dirty or clouded from smoke. Clean your filter by using window cleaner or a mild soapy solution and a soft cloth or paper towel (do not immerse in water or solution). Change the cover plates frequently. Storage Temperature -10 - 38°C (14 - 100°F)

Models with a replaceable battery will need the battery changed periodically when the Low Battery LED/LCD indicates.

Welding Helmets:

Welding helmets require virtually no maintenance other than periodic cleaning when dirty. Clean your helmet by using a mild soapy solution and a soft cloth or paper towel (do not immerse in water or solution).

DO NOT throw or abuse the helmet. Doing so may crack the helmet shell and compromise the protection.

Polycarbonate Protection (Cover) Plates:

Change cover plates when they lose flexibility and/or become bowed or distorted. Clean with mild soapy solution including any build-up from the area where the cover plate is retained. Discard if cleaning fails to improve visibility or cracks, scratches, etc. impair visibility.

Storage:

Equipment may be stored in original packaging or similar packaging. Store in a safe and dry location away from direct heat.

Spatter Protection

SPATTER DAMAGE IS NOT COVERED BY WARRANTY


Ensure that the helmet is always equipped with an Outside Cover Lens (in front of the filter, on the outside of the helmet) and an Inner Cover Lens (behind the filter, on the inside of the helmet). These protection lenses must be replaced if broken, warped, damaged, or covered with welding spatter such that vision is impaired. Replace regularly only with *ArcOne*® cover plates.

All helmets use 1 mm thick cover plates.

Parts Selection Guide


Headgear Height Adjustment Horizontal Adjustment Ratchet Knob Ratchet Knob 02-HG 06-HG Includes sweatband (not shown) Includes sweatband (not shown) Height Adjustment (Snap Out/ Slide/ Snap In) Height Adjustment (Snap Out/ Slide/ Snap In) Circumference Adjustment (Ratchet Push/Turn) Circumference Adjustment (Ratchet Push/Turn) Angle Adjustment (Pivot Stop) Angle Adjustment (Pivot Stop) Horizontal Adjustment (Slide Forward) Pivot Stop


COBRA



*Optional Mag Lens, VML-XXX, Where XXX=Diopter number (Not shown)

VISION®






COVER PLATE INSTRUCTIONS:

With notches facing up, slide one side of polycarbonate into guide clip. Align notches and push other side of polycarbonate into guide clip. Polycarbonate will click into place.

CENTER SECTION INSTRUCTIONS:

Slide A-D filter and Inside Polycarbonate into Filter Holder. Slide notches on top of Filter Holder into slots on helmet. Line up Filter Holder with Centering Pin on helmet, squeeze tabs on Filter Holder and push into tab slots. Release tabs into bottom catches.






Table 1. Filter Specifications

	iDF48	1000FcF	1500V	2000V	2500V	4000V	4500V				
Viewing Area	4608 mm ² (7.1 sq in)	3290 mm ² (5.2 sq in)	4416 mm ² (6.8 sq in)	4704 mm ² (7.3 sq in)	4704 mm ² (7.3 sq in)	3290 mm ² (5.2 sq in)	3290 mm ² (5.2 sq in)				
Filter Size	90x110 mm										
ARC	Two										
Sensing	Sensors										
Sensitivity Control	Digital: Variable	Analog: Variable	Analog: Variable	Analog: Variable	Analog: Variable	Digital: Variable	Digital: Variable				
Switching Time (seconds)	1/10,000 (0.1 msec)	1/10,000 (0.1 msec)	5/10,000 (0.5 msec)	5/10,000 (0.5 msec)	5/10,000 (0.5 msec)	1/10,000 (0.1 msec)	1/10,000 (0.1 msec)				
Primary Power	AAA Battery & Solar Cells	Solar Cells	Solar Cells	Solar Cells	Solar Cells	Solar Cells	Solar Cells				
Back-up Power	Lithium Battery										
Operating Temp.	-10-55C (14-131F)										
Storage Temp.	-10-38C (14-100F)	-10-38C -10-38C (14-100F) (14-100F)		-10-38C (14-100F)	-10-38C (14-100F)	-10-38C (14-100F)	-10-38C (14-100F)				
UV / IR Protection	Up to Shade 16	Up to Shade 13	Up to Shade 16								
Dark to Light Delay	0.1-3.5 seconds	0.1 or 2 seconds	0.2-2 seconds	0.1-2 seconds	0.2-2 seconds	0.1-3.5 seconds	0.1-3.5 seconds				
Light Shade	4	4 4		4	4	4	4				
Dark Shade	5-8/9-13	9-13	9-13	9-13	9-13	9-13	9-13				
Grind Mode	Yes	Yes	No	No	No	Yes	Yes				
Intelligent Auto-Shade Mode	Yes	No	No	No	No	No	No				
Intelligent TIG Mode	Yes	No No		No	No	No	No				
Enclosure Integrity	Dust/Water Resistant	Not Dust/Water		Dust/Water Resistant	Dust/Water Resistant	Dust/Water Resistant	Dust/Water Resistant				
Standards	² CE EN379	¹ CE EN379	⁴ CE EN379	⁴ CE EN379	⁴ CE EN379	² CE EN379	² CE EN379				
Optical Class	1	1	1	1	1	1	1				
Diffusion of Light Class	1	3	2	2	2	1	1				
Variation in Luminous Transmit- tance Class	1	1	1	1	1	1	1				
Angle De- pendency Class	2	N/A	3	3	3	2	2				
Inside Cover Plate Part Numbers	04-OP	03-OP	09-IP	03-OP	03-OP	04-OP	04-OP				

Table 1. Filter Specifications (cont.)

	5000V & 5000VX*	5130V & 5130VX*	5500V & 5500VX*	6000VI4	7000V & 7000VX*	7500V & 7500VX*								
Viewing Area	4608 mm ² (7.1 sq in)	4608 mm ² (7.1 sq in)	4608 mm ² (7.1 sq in)	8100 mm ² (12.5 sq in)	5684 mm ² (8.8 sq in)	5684 mm ² (8.8 sq in)								
Filter Size	90x110 mm	90x110 mm	90x110 mm	90x110 mm	90x110 mm	90x110 mm								
ARC Sensing	Two sensors	Two sensors	Two sensors	Four Sensors	Two sensors	Two sensors								
Sensitivity Control	Digital: Variable	Digital: Variable	Digital: Variable	Analog: Variable	Digital: Variable	Digital: Variable								
Switching Time (seconds)	1/10,000 (0.1 msec)	1/10,000 (0.1 msec)	1/10,000 (0.1 msec)	1/10,000 (0.1 msec)	1/10,000 (0.1 msec)	1/10,000 (0.1 msec)								
Primary Power	Solar Cells	Solar Cells	Solar Cells	Lithium Battery	Solar Cells	Solar Cells								
Back-up Power	Lithium Battery	Lithium Battery	Lithium Battery	None	Lithium Battery	Lithium Battery								
Operating Temp.	-10-55C (14-131F)	-10-55C (14-131F)	-10-55C (14-131F)	-10-55C (14-131F)	-10-55C (14-131F)	-10-55C (14-131F)								
Storage Temp.	-10-38C (14-100F)	-10-38C (14-100F)	-10-38C (14-100F)	-10-38C (14-100F)	-10-38C (14-100F)	-10-38C (14-100F)								
UV / IR Protection	Up to Shade 16	Up to Shade 16	Up to Shade 16											
Dark to Light Delay	0.1-3.5 seconds			0.1 or 2 seconds	0.1-3.5 seconds	0.1-3.5 seconds								
Light Shade	e 4 4		4	4	4	4								
Dark Shade	9-13			9-13	5-9/9-13	5-9/9-13								
Grind Mode	Yes	Yes	Yes	Yes	Yes	Yes								
Intelligent Auto-Shade Mode	No	No	No	No	No	No								
Intelligent TIG Mode	No	No	No	No	No	No								
Enclosure Integrity	Dust / Water Resistant	Dust / Water Resistant	Dust / Water Resistant	Dust / Water Resistant	Dust / Water Resistant	Dust / Water Resistant								
Standards	² CE EN379	4CE EN379	² CE EN379	¹ CE EN379	² CE EN379	² CE EN379								
Optical Class	1	1	1	1	1	1								
Diffusion of Light Class	1	1	1	2	1	1								
Variation in Lu- minous Trans- mittance Class	1	1	1	1	1	1								
Angle Dependency Class	2	2	2	1	1	1								
Inside Cover Plate Part Numbers	04-OP	04-OP	04-OP	04-OP	10-IP	10-IP								
*Eiltor variante	designated wit	h (V) hava V T	IC made at the	highoot concit	ivity cotting C	o Concitivity								

*Filter variants designated with (X) have X-TIG mode at the highest sensitivity setting. See Sensitivity Adjustment section for details.

Significance of Markings:

Welding Filters:

Example: 4 / 5-8/9<13 AR M 1/1/1/2 EN379

4 – Light Shade number 5-8 – Dark Shade range 1

9<13 – Dark Shade range 2 (Auto-Variable mode)

AR - Manufacturers mark

M - Auto Variable

1 - Optical Class

1 - Diffusion of Light Class

1 - Variation in Luminous Transmittance class

2 – Angle Dependency class (This is a new classification of EN379. This marking may not be indicated on older models.)

Welding Helmets:

Significance of CE Markings: Example: AR EN 175 -F CE AR – Company Identification Mark EN 175 – CE Welding Helmet Standard -F – Impact Class (Low Energy) CE – European Mark

Significance of Other Markings:

Example: AR Z87

AR – Company Identification Mark

Z87 - ANSI Standard for Eye and Face Protectors

Example: CAN/CSA Z94.3 COLTS Labs

CAN/CSA Z94.3 - CSA Standard for Eye and Face Protectors

COLTS Labs – CAN/CSA Certified Lab

Product Certification Bodies

¹This model has been certified by: Certottica SCARL Zona Industriale Villanova

32013 Longarone (BL), Italy Notified Body Number: 0530

²This model has been certified by: ECS GmbH

Obere BahnstraBe 25 73431 Aelen - Germany Notified Body Number: 1883

³This model has been certified by: INSPEC International

56 Leslie Hough Way

Salford

Greater Manchester M6 6AJ, England

Notified Body Number: 0194

⁴This model has been certified by: DIN CERTCO


Alboinstrasse 56 12103 Berlin, Germany Notified Body Number: 0196 *indicates pending certification

Table 2: Shade Selection Guide

CE Shade selection Guide

													Surren Amps													
Process	1.5	6	т	10	15	30	40	60	70	0 T	100	125			175	200	1 2	25	250	300	35	50 T	400	450	500	600
Covered Electrodes			_	_	8	•	-	Ί	9)	I	10	Ί	_	11		_	12	2	Τ	_	13	3	T	14	_
MAG					8					9	Τ	10			1	1				12					13	1-
TIG					8			9			10	_		11		I		12	2	I	13					
MIG with heavy metals											9	_	10				11		Ι	12			13	I	14	
MIG with light metals													10			11			12	Т	1	3		14		
Air-arc gouging							10)								11		12	2	13			14	Τ	15	5
Plasma jet cutting												9	10	11			12		T		13					
Micro-plasma arc welding	1.5	4 6	_	5 10	15	6	40	7 60	8		100	125	10		175	11	2	25	12 250		35	50 T	400	450	500	600
NOTE: The term "heavy r																		1	_,,,	,,,,,					, ,,,,,	, ,,,,

Filter Removal Diagram





ArcOne® is a Division of A.C.E. International Company 85 Independence Drive, Taunton, MA 02780, USA

TEL: 1+(508) 884-9600 • TOLL FREE: +1 800) 223-4685 • FAX: (508) 884-9666

PLEASE VISIT OUR WEBSITE: www.arc1weldsafe.com